EXS2_EXM2 User Documentation Files

• The EXS2_EXM2 user documentation available here has been divided among a number of files in order to facilitate downloading. You can download the entire manual, or you can save time by using the table of contents below to find specific information and then download only the files you need.

File 1 (File name : EXS2_EXM2_e_1.pdf)

2 INTRODUCTION

Unpacking 2
Features 8
Precautions 9
- General Precautions 9
- Data Error Precautions 11
- Operating conditions 11
- Condensation 12
- LED Backlight 12
- Lens 12
- Other 13

14 QUICK START GUIDE

Getting Ready 14
Configuring Display Language and Clock Settings ... 15
To record an image 15
To view a recorded image 16
To delete an image 16

17 GETTING READY

General Guide 17
- Camera 17
- USB Cradle 18

Using the Controller 19
Monitor Screen Contents 20
Indicator Lamps 22
Attaching the Strap 22
Power Requirements 23
- To load the battery 23
- To charge the battery 24
- Power Supply Precautions 28
- Turning the Camera On and Off 29
- Auto Power Off (APO) 29

Using the On-screen Menus 30
Configuring Display Language and Clock Settings ... 32

34 BASIC IMAGE RECORDING

Recording an Image 34
- About the REC Mode Monitor Screen 35
- Recording Precautions 35

Using Zoom 36
Using the Flash 37
- Flash Precautions 38

Using the Self-timer 39
Specifying Image Size and Quality 40
- To specify the image size 40
- To specify the image quality 41

42 OTHER RECORDING FUNCTIONS

Exposure Compensation (EV Shift) 42
Adjusting the White Balance 43
- Adjusting White Balance Manually 44

Using the Best Shot Mode 45
Using the Movie Mode 46
Recording Audio (EX-M2 Only) 48
- Adding Audio to a Snapshot 48
- Recording Your Voice 49

REC Mode Camera Settings 51
- Turning the Monitor Screen On and Off 51
- Turning Image Review On and Off 51
- Assigning Functions to the Controller 52
- Specifying Power On Default Settings 53

54 PLAYBACK

Basic Playback Operation 54
- Playing an Audio Snapshot (EX-M2 Only) 55

Zooming the Displayed Image 56
Resizing an Image 57
Playing a Movie 58
Adding Audio to a Snapshot (EX-M2 Only) 59
- To re-record audio 60

Playing Back a Voice Recording File (EX-M2 Only) ... 61

62 DELETING FILES

Deleting a Single File 62
Deleting All Files 63

File 2 (File name : EXS2_EXM2_e_2.pdf)

64 FILE MANAGEMENT

Folders 64
- Memory Folders and Files 64

Protecting Files 65
- To protect a single file 65
- To protect all files in memory 66

DPOF 66
- To insert the date during printing 67
- To configure print settings for a single image 67
- To configure print settings for all images 68

PRINT Image Matching II 69
Exif Print 69
Using the FAVORITE Folder 70
- To copy a file to the FAVORITE folder 70
- To display a file in the FAVORITE folder 71
- To delete a file from the FAVORITE folder 71

72 OTHER SETTINGS

Turning the Key Tone On and Off 72
Specifying an Image for the Startup Screen 72
Changing the Date and Time Setting 73
Changing the Date Format 74
Changing the Display Language 74
Formatting Built-in Memory 75

76 USING A MEMORY CARD

Using a Memory Card 77
To insert a memory card into the camera 77
To remove a memory card from the camera 77
Formatting a Memory Card 78
Memory Card Precautions 79
Copying Files 79
To copy all the files in built-in memory to a memory card 79
To copy a file from a memory card to built-in memory 80

81 USING THE CAMERA WITH A COMPUTER

Installing the Software from the CD-ROM 81
About the bundled CD-ROM 81
Computer System Requirements 82
Installing Software from the CD-ROM in Windows ... 83
Getting Started 83
Selecting a Language 83
Viewing the Contents of the “Read me” File 84
Installing an Application 84
Viewing User Documentation (PDF Files) 85
Exiting the Menu Application 85
Installing Software from the CD-ROM on a Macintosh 85
Installing Software 85
Viewing User Documentation (PDF Files) 88
Transferring Files to a Computer 89
Transferring Files Over a USB Connection 89
Using a Memory Card to Transfer Images to a Computer 92
Memory Data 93
Memory Directory Structure 94
Image Files Supported by the Camera 95
Built-in Memory and Memory Card Precautions 95

96 PLAYING AN AUDIO FILE (EX-M2 Only)

Transferring Audio Files to the Camera 96
Preparing the Camera for Audio Player Operation ... 97
Using the Camera as an Audio Player 98
General Guide 98
Basic Remote Controller Operations 100
Specifying the Audio Playback Mode 101
Selecting a Specify Track for Playback 101
Specifying the Track Playback Sequence 102
Disabling Remote Controller Button Operations 104
LCD Remote Control Error Messages 105
Audio Playback Precautions 105

106 APPENDIX

Menu Reference 106
Indicator Lamp Reference 107
Camera Indicator Lamps 107
USB Cradle Indicator Lamps 109
Troubleshooting Guide 110
Display Messages 113
Specifications 114
Main Specifications 114